

PORTAVALIGIE LATERALE SPECIFICO - SPECIFIC TUBULAR SIDE-CASE HOLDER
 PORTE-VAISES LATÉRAUX SPÉCIFIQUE - SPEZIFISCHES STAHLROHR-SEITENTRAEGER
 PORTA MALETAS LATERALES ESPECÍFICO

BMW F650GS 2000-2007

BMW G650GS 2011

ISTRUZIONI DI MONTAGGIO - MOUNTING INSTRUCTIONS
 INSTRUCCIONES DE MONTAJE - BAUANLEITUNG - INSTRUCCIONES DE MONTAJE

ATTENZIONE - WARNING - ATTENTION

IL SUPPORTO "A" VA INSERITO TRA IL FIANCHETTO ED IL SILENZIATORE.

THE UPPER SUPPORT "A" MUST BE INSERTED BETWEEN SIDE PANEL AND THE SILENCER

LE SUPPORT "A" DOIT ÊTRE INSERÉ ENTRE LE CÔTE PLASTIQUE ET LE POT.

①



SUPPORTO
SUPPORT
SUPPORT
HALTERUNG
SOPORTE

Q.TY n.2(Dx-Sx)


②



PONTE POSTERIORE
REAR BRIDGE
PONT POSTÉRIEURE
VERBINDERINGSROHR
PUENTE TRASERO

Q.TY n.1


③



VITE TBEI M8x20mm
SCREW
VIS
SCHRAUBE
TORNILLO

Q.TY n.2


④



VITE TBEI M6x16mm
SCREW
VIS
SCHRAUBE
TORNILLO

Q.TY n.2


⑤



VITE TBEI M8x25mm
SCREW
VIS
SCHRAUBE
TORNILLO

Q.TY n.2


⑥



VITE TEF M8x25mm
SCREW
VIS
SCHRAUBE
TORNILLO

Q.TY n.2


⑦



RONDELLA Ø6mm
WASHER Ø6mm
RONDELLE Ø6mm
SCHEIBE Ø6mm
ARANDELA Ø6mm

Q.TY n.2

⑧



RONDELLA Ø8mm
WASHER Ø8mm
RONDELLE Ø8mm
SCHEIBE Ø8mm
ARANDELA Ø8mm

Q.TY n.2

⑨



DISTANZIALE Ø14x3mm
Foro Ø8,5mm, V379
SPACER
ENTRETOISE
DISTANZSTÜCK
DISTANCIADOR

Q.TY n.2


⑩



FISHER Ø30X25
RIB. 23,7x21 Ø17,4
V695
EXPANDING TUBE INSERT
CHEVILLE
ELASTISCHER ROHREINSATZ
TACO

Q.TY n.2

⑪



CONO FILETTATO
Ø20.4 a 18.8 M8
V697
THREADED CONE
CÔNE FILETÉ
KEGEL GEWINDE
CONO ROSCADO

Q.TY n.2

⑫

COMPONENTI ORIGINALI
ORIGINAL PARTS
PARTIES ORIGINALES
ORIGINAL BAUTEILE
COMPONENTES ORIGINALES

Q.TY n.-

