


Montage Sport Scheibe - Sport screen instructions

6531313




| NR | Teile / PARTS | Menge | BESCHREIBUNG | DESCRIPTION |
|----|---|-------|--|---|
| 1 |  | x1 | Ermamax Sport Scheibe h : 25 cm | Ermamax Sport screen h : 25 cm |
| 2 |  | x1 | Unterbau | Sport screen support |
| 3 |  | x4 | <i>Originalschraube Ø5 x 20 (Armaturenbrett)</i> | <i>Ø5 x 20 Original screw (dashboard)</i> |
| 4 |  | x3 | Schraube M4 x 15 schwarz | M4 x 15 Black BHC screw |
| 5 |  | x3 | Kunststoffunterlegscheibe Ø4 | Ø4 Nylon washer |
| 6 |  | x3 | Gummi Dübel M4 | M4 Rubber insert |

1 Demontage - Disassembly



Montage - Assembly 2



3 Montage Assembly

